

## ARCH (PATTERNS)

### Zintra Tiles - New Releases - Walls



Texture: 3

Lustre: 1

Transparency: 1

<b>DESCRIPTION / FEATURES</b>	Offering 6 new, progressive and easy to install designs, Pattern Tiles continue to be a Zintra favorite. The 28 front and back colors create thousands of possible combinations even before you decide how to lay them out on the wall. Check out the Zintra 12mm color range <a href="#">here</a> or the <b>DOWNLOAD</b> tab below for a pdf.
<b>HOW TO SPECIFY</b>	1. Design 2. color
<b>COMPOSITION</b>	Zintra Acoustic Panel - 100% Solution Dyed (color through) Polyester
<b>FINISHES AVAILABLE</b>	<a href="#">Zintra 12mm (1/2") Colour Range</a>
<b>STANDARD SIZE</b>	16 tiles / set, 25.7 SF (2.4m <sup>2</sup> ) 15.93" (405mm) x 23.62" (600mm)
<b>INDOOR/OUTDOOR</b>	Indoor only
<b>WET AREAS</b>	No
<b>SUGGESTED INSTALLATION</b>	Check out the <b>DOWNLOAD</b> tab for a complete Handling and Installation guide. Supplied as a set of individual tiles. Arrange as required. Adhere to substrate using contact adhesive, Liquid Nails or Z clips.

<b>CUSTOMISABLE</b>	Size - Yes.Zintra color - Yes. Contact Baresque for details
<b>THERMOFORMABLE</b>	No
<b>BRAND SPEC</b>	ZINTRA
<b>ENVIRONMENTAL INFORMATION</b>	ASTM E-84 Class A1 Standard Fire Retardant Class 1 Eco Cycle Class A1 Standard Recycling Score 12
<b>ADDITIONAL COMMENTS</b>	NRC - 0.45 - 0.90.Sold in sets.Not suitable as a free standing product.
<b>FABRICATION</b>	Stanley knife if required
<b>REFINISHABLE</b>	No
<b>CARE INSTRUCTIONS</b>	<p>Remove spills immediately using damp, clean cloth.</p> <p>Dab Zintra with a clean, soft white cloth dampened with a mild solution of liquid detergent and warm water. Repeat using only clean water, then pat dry with a lint free cloth.</p> <p>Avoid using wax polishes, solvents or concentrated abrasives.</p> <p>For more difficult stains, dampen a soft white cloth with a solution of household bleach (10% bleach / 90% water). Dab gently. Repeat using only a clean, water dampened cloth to remove bleach concentration then pat dry with a lint free cloth.</p> <p>Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Baresque for assistance.</p>